



- 1. Main frame
- 2. 'M' frame
- 3. 'L' frame

- 4. Wheel
- 5. Solid axle and R-clip
- 6. Plastic knob

- 7. Handle
- 8. Bag
- 9. 2x Metal sleeves

Unpack all components and make sure all listed are present before commencing assembly.

1. Unfold the two rear legs, and locate the welded nut on the right side and tighten the legs in position using one plastic knob as shown below.



2. Insert the two L shaped sections into the main frame, and tighten using two plastic knobs as shown below.



3. Insert the axle and position the two metal sleeves, before inserting the wheel into its location on the L Shaped sections using the spindle and 2 R clips as shown below.



Instructions for use

Fishing Barrow

4. Insert the M shaped frame to the front of the main frame, using two plastic knobs and tighten as shown below.



5. Insert the two handles into back of the main frame, making sure both are positioned equally in depth. Tighten using two plastic knobs as shown below.



6. Position the bag into the back of the main frame using the hook and loop tape on all sides to secure then position the straps and connect the plastic fastenings and tighten straps to desired tension as shown below.



- Clean the barrow with warm soapy water; do not use harsh abrasives or chemicals.
- Ensure the barrow is dry before storage and store in a cool, dry place.
- To prevent rusting, periodically lubricate the metal parts of the wheel.